02SNO0705-V4-PEFC

7x5 Snowdrop Playhouse



WARNING: Only for domestic use
Not suitable for children under 36 months due to
small parts and danger of falling from heights.
To be used under direct supervision of an adult



BEFORE YOU START PLEASE THE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed in the parts list provided.
- When you are ready to start, make sure you have the right tools at hand (not supplied) including a Phillips screwdriver, Flathead screwdriver, Stanley knife, Wood saw, Step ladder, Hammer, Spirit level and a Drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.
- Ensure you have enough time to build the product to ensure the building is water tight.

TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due natural processes. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of hot weather and sheltered as much as possible during rain or snow.

Our buildings are pre treated with a water based treatment**; this only helps to prevent discolouration whilst in stock. To validate your guarantee and ensure longevity of the product, it is ESSENTIAL the building is treated with a suitable preservative in accordance with the manufacturers recommendations. Care must be taken to ensure the product is placed on a suitable base.

We recommended using a suitable protection for your playhouse. As the product is destined for use by children, a water based treatment that is EN71 tested for children is ESSENTIAL.

We also recommend treating the building prior to construction.

POSITIONING YOUR PLAYHOUSE

When thinking about where the building and base is going to be constructed: Ensure that there will be access to all sides for maintenance work and annual treatment.

We recommend a minimum space of 2m around a playhouse , away from any structure or obstructions such as fences, garages, houses, overhanging branches, washing lines or electrical wires.

It is recommended that the position of the Playhouse, Slide and Swing is not in direct sunlight.

Activity toys such as swings and slides for towers shall not be installed over concrete, asphalt or any hard surface.

BUILDING A BASE

Ensure the base is level and is built on firm ground, to prevent distortion, checking with a spirit level. Refer to diagrams for the base dimensions. The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.
- Wooden base.

WARNING

- ONLY SUITABLE FOR DOMESTIC USE.
- TO BE USED UNDER DIRECT SUPERVISION OF AN ADULT.
- THIS PRODUCT SHOULD NOT BE MODIFIED IN ANY WAY. ANY MODIFICATIONS SHOULD BE DETERMINED BY THE MANUFACTURER AND CARRIED OUT ACCORDING TO THE INSTRUCTIONS.
- DO NOT ALLOW YOUR CHILD TO PLAY WITH ANY COMPONENT PARTS PRIOR TO ASSEMBLY.
- MAX AGE OF 14 YEARS.
- THIS TOY IS FOR OUTDOOR USE ONLY.
- USE A WATER BASED TREATMENT THAT IS EN71 TESTED

CAUTION

Wood is a natural product and can change post manufacture. So despite every effort being made to ensure the material used are cut and machined to a clean and smooth finish, care must be taken when handling the product and preparing for use by your child.

Any areas of concern, in the play areas, can be rubbed over with sandpaper to achieve a smoother finish. Alternatively, call the customer service department who will be happy to arrange replacement panels/parts.



All buildings should be erected by atleast two adults.
DO NOT ALLOW
CHILDREN TO ASSIST.



Winter = High Moisture = Expansion Summer = Low Moisture = Contraction



2mm Drill bit 12mm CSK

To prevent damage during assembly, you MUST pilot drill all screw holes and ensure all screw heads are countersunk.



For ease of assembly, you will need a tape measure to check dimensions of components.

Whilst all products manufactured are made to the highest standards of Safety and in the case of childrens products independently tested to EN71, we cannot accept responsibility for your safety whilst erecting this product.

**Protim Aquatan T

Your building has been treated with Aquatan .

Aquatan is a water-based concentrate which is diluted with water, the building as been treated by the correct application of Aquatan solution and then allowed to dry.


Aquatan is a decorative finish to colour the wood, which is applied industrially to timber fence panels and garden buildings.

Aquatan undiluted contains: boric acid, sodium hydroxide 32% solution, aqueos mixture of sodium dioctyl sulphosuccinat and alcohols: 2, 4, 6-trichlorophenol.

In all instances for assistance with your product, please contact customer care on: 01636 880514 or customerservice@merciagp.co.uk

Mercia Garden Products Limited, Sutton On Trent, Newark, Nottinghamshire, NG23 6QN







Overall Dimensions: Width = 2310mm Depth = 1819mm


Height = 2020mm

Base Dimensions: Width = 2082mm Depth = 1448 mm


















Pre Assembly

Before assembling remove the transportation blocks from the bottom of each panel.

Take care removing the blocks as to not damage the panels. Tap with a flat headed screwdriver and hammer.

Dispose of the blocks once removed.



12mm

Parts needed - 11k3 & 34k6










To fix the Windows into the panels that accomodate a window. Position the Window (No. 11) central into the window opening. Fix the Window Block (No. 34) to the Window central as shown with 1x30mm screw.

Place the Window into the window hole and fix by screwing though the Window Block with 2x30mm screws as shown.

18x30mm screws.





Step 2 Parts needed - 1 & 10 & 32 x3







Lay the Door Gable (No. 1) with the boards facing up on a flat surface. Place the door within the door aperture and position the Door (No. 10) so that you have a 12mm gap from the door to the door gable on all four sides.


Useful tip: Use a12mm thick piece of timber from your fixing kit within the gaps to ensure the door does not move.

Place a Hinge x3 (No. 32) at the top, middle and bottom of the door and using 7x30mm black screws per hinge, fix the hinge to the door and the door gable.

21x 30mm black screws












Place the Floor (No. 5) on your firm and level base, ensure base has suitable drainage free from areas where standing water can collect. (See front page on base requirements).




12mm











055mm








COMPONENT PARTS PRIOR TO ASSEMBLY.

Step 8 Parts needed - 23 & 24






Then fix the Bunk Floor Block C (No. 23) onto the framing as shown in the diagram. Fix using 1x40mm screw in the left of the block through the framing.

Fix with a 1x40mm screw down into block D.

3x40mm screws





Step 10 Parts needed -














Away from the building, fix the Bunk Floor Block A (No. 21) x2 to the Bunk Floor (No. 6) from underneath. Fix through the framing into the blocks using 4x50mm screws.



Step 9 Parts needed - 23 & 24 x2






Fix the other 2x Bunk Floor Block D (No. 24) to the door gable using 1x40mm screw through the framing into each block as shown in the diagram.

Then fix the Bunk Floor Block C (No. 23) onto the framing as shown in the diagram. Fix using 2x40mm screws down into block D.

4x40mm screws





Parts needed -






To assemble the ladder, slot each Ladder Step x3 (No. 20) into the grooves of the Left and Right Ladder Sides (No. 19). Fix with 4x50mm screws per step as shown.

12x50mm screws.












P 7




COMPONENT PARTS PRIOR TO ASSEMBLY.

Step 16

Once the roof is fitted and the building is square, secure the building to the Floor fixing the panels onto the floor using 18x50mm screws in alignment with the floor joists.

18x50mm Screws












A Fix the Support Block (No. 18) between the apex of the roof flush with the edge of the roof sheets using 2x30mm screws.

B Fix the Fascia Block (No. 17) in the middle of the the Large roof sheet using 2x30mm screw, ensuring it is flush with the edge.

4x30mm Screws







Cut felt into 3 sheets and lay onto roof as shown in diagram ensuring there is a 50mm overhang around the sides.


Fix using felt tacks at 100mm intervals.


80 Felt Tacks











Step 19

Parts needed - 15 x2 & 16 x2 & 25 x2

Fix the Fascia 1427mm x2 (No. 15) to the front and back using 3x40mm screws.

Fix the Fascia 1041mm x2 (No. 16) to the front and back using 2x40mm.

Fix the Finials x2 (No. 25) to the front and back using 2x40mm screws.

Ensure to trap the felt between the fascia and the building.

7x40mm Screws



Step 20

Parts needed - 29 x2 & 30 x4

Fix a Window Box x2 (No. 29) and Window Shutters x2 (No. 30) to each window on the Door Gable.

Fix a Window Box (No. 29) underneath the window, screwing through the Door Gable into the window box using 4x30mm screws.

Fix the Window Shutters x2 (No. 30) through the Door Gable into the shutter using 4x30mm screws per shutter.


Repeat with both windows.

12x40mm screws.





Every effort has been made to reduce sharp edges but it is recommended



Step 21 Parts needed - 26 x3 & 27 & 28 & 31











Place the Wooden Door Handle (No. 31) on the outside of the door and use a 60mm screw from the inside to secure.

On the inside of the door opening fix the ply triangle door stop (No. 28) to the bottom left corner using 3x20mm screws.


Fix the Butterfly (No. 27) onto to the door using 4x10mm screws.


4x10mm Screws 15x20mm Screws 1x60mm Screw

























Playhouse Maintenance:

It is recommended that the following checks and maintenance are carried out at the begin ning of each season as well as at regular intervals during the usage season.

- Check all nuts /bolts/ screws for tightness and tighten when required.
- Check for movement / opening of wood giving rise to protrusion of nail heads and tips.
- Check hinges.
- Replace defective parts in accordance with the manufacturers instructions.
- Check any crossbeams, suspensions and anchors.
- If a swing is included; check the swing seat, chains and ropes.

IF THESE CHECKS ARE NOT CARRIED OUT THE ACTIVITY TOY COULD BECOME A HAZARD