# **General Fitting Guide for Shower Panel**

#### **Guarantee & Aftercare**

When installing or using tools, extra care must be taken to avoid damaging the finish or fitting. To maintain the appearance, please ensure it is cleaned regularly using a clean soft damp cloth only. Abrasive cleaners or detergents must not be used as they may cause surface deterioration. The company provides a guarantee against faulty material or manufacture excluding serviceable parts, providing they have been installed, cared for and used in accordance with our instructions

## Water Supply Regulations

This product has been manufactured to comply with the appropriate BS EN Standards and to confirm to Water Supply Regulations

#### Earth Bonding

Earth any new pipework satisfactorily (Seek expert advice if in any doubt)

#### **Operating pressures**

Minimum operating pressure is 2 bar, max is 5 bar. Please note hot supply is on the left and cold on the right. These are indicated on the flexi pipes

## Cleaning & maintenance

To maintain the surface of your product, wipe with a clean damp cloth and wipe dry, do not use any abrasive cleaning agents or materials.

The company reserves the right to continually evolve its product lines without notification. The company will not accept any liability regarding specification changes and their consequences unless previously quoted by the company in writing.

# Installation Procedure

- 1. Ensure you have all the relevant tools before commencing the installation.
- 2. Prior to installation, please ensure all the supply pipes have been flushed through to remove any debris and then ensure the water supply is turned off.
- 3. Connect the fixing bracket to the wall, making sure you use suitable fixings.
- 4. Connect the shower handset parking bracket to the side of the shower panel, and secure in place using the locking mechanism provided.
- 5. Secure the conical end of the shower flex to the shower handset, and the other end of the shower flex to the water outlet on the underside of the handset parking bracket. The handset can now rest in the parking station.
- 6. Connect the hot / cold water supply pipes on the reverse of the shower panel to water inlet feeds.
- 7. Hook the shower panel onto the wall fixing bracket.
- 8. Run the water for a few minutes to flush out any debris.
- 9. Check all water feed connections to ensure there are no leaks.
- 10. Check the final position of the product to the wall to ensure there is no water ingress that may cause water damage after installation.

11. To operate the shower panel, simply decide which of the three shower outlets you wish to use, then press the corresponding button to activate. Pressing the button again will stop the flow of water.

