


Tools required for installations



handle is fixed in middle of drawer panel
as below

