


furniture123

Built in Media Wall

SKU: AGL082

Product Size 178 cm x 44 cm x 220 cm

Estimated Assembly Time: 2 people 1 hour



EPD 1/2021


Cabinetry Care and Maintenance

Congratulations with your recent purchase, and thank you from the Furniture123 team. In order to get the most out of this piece of furniture, special care and maintenance should be followed, explained below:






- We suggest you retain these instructions for future reference
- This product should only be used on firm level ground
- To avoid the risk of suffocation to children and animals, dispose of plastic bags immediately.
- Please periodically check all fittings and re-tighten as necessary.
- Please do not sit or stand on your furniture
- Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour
- Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth
- Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing
- Do not drag or pull your furniture
- Do not use silicon based furniture polish. Silicone in furniture polishes can break down the lacquer finish
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate
- Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster
- If the product contains glass which is chipped or broken, consult Furniture 123
- When cleaning glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances scratch glass panel
- Dust regularly with a soft cloth, preferably once a week
- Never allow any kind of liquid to remain on your furniture.

EXPLODED DIAGRAM




PARTS SUPPLIED


NOTE: Pictures and contents in this manual may differ from the product due to continuous product improvement.

PART	DIAGRAM	DESCRIPTION	QTY
U1		M4X25 screw	42 PCS
U2		Pin	38 PCS
U3		Cam	38 PCS
U4		M6x23 screw	16 PCS
U5		mounting bracket	2 PCS
U6		M4X14 screw	20 PCS
U7		4-hole bracket	4 PCS
U8		plastic wall anchor	6 PCS
U9		M5X60 screw	6 PCS
U10		L-shaped bracket	2 PCS
U11		M5x10 screw	2 PCS
U12		Shakeproof washer	6 PCS
U12		M4X30 screw	4 PCS


ASSEMBLY




Step 1 : For ease of installation, panel A and panel B can be laid flat first. Attach panel A to panel B with 6 screws [U1].




Step 2 : Attach panel C to panel B with 6 screws [U1]. Attach panel D to panel B with 6 screws [U1].





Step 3 : Attach panel E to panels C and D with 2 screws [U1].




Step 4 : Attach panels F and G to panel A with 4 screws [U1].




Step 5 : Attach panel J to panel K with 4 pins [U2] and 4 cams [U3]. Attach panel H to panel I with 4 pins [U2] and 4 cams [U3].




Step 6 : Attach panel L to panels K and I with 2 pins [U2] and 2 cams [U3].



Step 7 : Attach panel M to panels K and I with 2 pins [U2] and 2 cams [U3].




Step 8 : Attach panel H to panel L with 2 screws [U1]. Attach panel J to panel L with 1 screw [U1]. Attach panel H to panel M with 2 screws [U1]. Attach panel J to panel M with 1 screw [U1].




Step 9 : Pre-embed 3 cams [U3] into panel L. Pre-embed 3 cams [U3] into panel M.


CAUTION: The pointed positions of cams [U3] on both sides facing each other.




Step 10 : Attach panel N to panel L with 3 pins [U2]. Attach panel O to panel M with 3 pins [U2]. After fully inserting, lock with cams [U3].




Step 11 : Attach panel U to panel J with 2 pins [U2] and 2 cams [U3]. Attach panel V to panel J with 2 pins [U2] and 2 cams [U3].




Step 12 : Attach panel U to panel L with 2 screws [U1]. Attach panel V to panel M with 2 screws [U1].




Step 13 : Place the component completed in step 12 vertically onto the component completed in step 4.




Step 14 : Attach panel C to panel L with 4 screws [U1]. Attach panel D to panel M with 4 screws [U1].




Step 15 : Attach panel P to panels K and I with 4 pins [U2] and 4 cams [U3].




Step 16 : Attach panel Q to panels K and I with 4 pins [U2] and 4 cams [U3].




Step 17 : Attach panel Q to panels K and I with 4 pins [U2] and 4 cams [U3].




Step 18 : Attach panel R to panels K and I with 4 pins [U2] and 4 cams [U3].



Step 19 : Attach panel S to panels P, Q, Q and R with 8 screws [U4]. Attach panel T to panels P, Q, Q and R with 8 screws [U4].




Step 20 : Attach panel L and panel S with 1 4-hole bracket [U7] and 4 screws [U6]. Attach panel L and panel T with 1 4-hole bracket [U7] and 4 screws [U6]. Attach panel M and panel S with 1 4-hole bracket [U7] and 4 screws [U6]. Attach panel M and panel T with 1 4-hole bracket [U7] and 4 screws [U6].




Installation of heater

Note: This unit has been designed for AGL067W. Other fires will not fit correctly.


Step 1 : Fix 2 L-shaped brackets [U10] with 2 screws [U11] and 2 shakeproof washers [U12] on top of the heater.



Step 2: Place the heater into the TV cabinet.



Step 3 : Attach 2 L-shaped brackets [U10] to panel H with 4 screws [U6] and 4 shakeproof washers [U12].




Refer to the instructions supplied with the fire to ensure correct installation and ventilation.


Wall mount

Note: The fixing supplied are suitable for a masonry wall. Check the construction of your wall and use appropriate fixings. Beware of cables and pipework that maybe in the wall.


Step 1: Select the wall location where you want to install your TV cabinet. Draw two vertical lines using a vertical instrument and mark 6 drill holes for the 6 anchor screws.




Step 2: Drill 6 holes 8 mm (5/16in) in diameter and 43 mm (1.7in) deep on the marked locations. Insert 6 plastic wall anchors [U8] into the holes and gently tap until the flange on the anchors are against the wall surface.



Step 3: Secure the mounting brackets [U5] to the wall anchors using the 6 anchor screws [U9].



Step 4: Place the TV cabinet. Secure the TV cabinet to the mounting brackets [U5] using the 4 screws [U12].




Installation of television


Note: This unit is designed for televisions with up to 60 inch screens, with a maximum overall size of 135 x 78 cm and a maximum weight of 45 KG.

CAUTION: The accessories supplied with your Television may differ from those shown here, and the following details are for reference only.


1. Plan the position of the TV and bracket before drilling any holes.
2. Follow the bracket supplier's instructions, remembering that you are fitting to a wooden panel.
3. For neat installation you may want to cut cable holes in the panel to feed mains and data aerial cables from your TV.




Step 1: Fix 2 wall mounting brackets [2] to the back of the TV with 4 plastic washers [3], 4 screws [5] and 4 washers [4].



Step 2: Fix the wall bracket [1] to the TV cabinet with 4 screws [6] and 4 washers [4].



Step 3: Connect the wall mounting bracket [2] on the back of the TV to the wall bracket [1].



Step 4 : After fixing the two brackets [1,2], use 2 screws [5] to secure the TV in place.

