

1. Identify all components are present prior to installation.
2. Remove screw (2) form flange (3), then remove the flange from the waste body (6).
3. Secure the waste body (6) against the underneath of the bath with the sealing washer (5) in position. Use the flange (3) with the rubber washer (4) between the flange & the bath, securing the assembly with screw (2).
4. It is recommended that a silicon sealant be applied to all sealing faces of the washer (4).
5. Replace screw (2). Do Not over tighten.
6. Use the conical washer (7) & nut (8), in the order shown, to hold the tube (9) into the waste body (6).
7. Use the same process to assemble the overflow elbow (10) to the tube (9).
8. Secure the overflow elbow (10) to the bath using the sealing washer (11) & the overflow washer (12), positioned either side of the bath surface. Then place the overflow (13) o top of the overflow washer (12) & secure the assembly using screw (14).
9. It is recommended that a silicon sealant be applied to both sealing faces of washer (12).
10. Tighten screw (14). (DO NOT OVER TIGHTEN).
11. Check all joints & connections for leaks.
12. Please be advised that no abrasive agents or materials or harsh chemicals can be used for cleaning this product, otherwise warranty will be void. Please clean with warm soapy water, use soft cloth only.
13. The overflow pipe can be cut to size if need.

Components

1. Plug
2. Screw
3. Flange
4. Rubber washer
5. Sealing washer
6. Waste body
7. Conical washer
8. Nut
9. Chrome tube (over sizes)
10. Overflow elbow
11. Overflow seal washer

